

## Wiring of XLR -> LEMO cables

XLR female plug shown from solder side

XLR pin 2: hot    XLR pin 3: cold

XLR pin 1: connect ground wire to one plug only.

(It is preferred to connect ground at one point only in order to avoid making a ground loop)

